

006712

Service Kit LW 100 B

500 hours

- 1x 001810 – O-ring of water separator
 - 1x 001735 – Sintered filter of water separator
 - 1x 001769 – O-ring of final filter tower
 - 1x 001237 – O-ring of DIN filling connector
 - 1x 001224 – O-ring of rotatable hose
 - 1x 001708 – Intake filter cartridge
 - 1x 002309 – Breathing air filter cartridge
 - 1x 000001 – Compressor oil (1l)
-

006713

Service Kit LW 100 B

1000 hours

- 1x 001810 – O-ring of water separator
- 1x 001735 – Sintered filter of water separator
- 1x 001769 – O-ring of final filter tower
- 1x 001237 – O-ring of DIN filling connector
- 1x 001224 – O-ring of rotatable hose
- 1x 001705 – Gasket (1st stage)
- 2x 001777 – O-ring (2nd and 3rd stage)
- 1x 001771 – O-ring (3rd stage)
- 1x 001781 – O-ring (1st stage)
- 1x 001768 – O-ring (2nd stage)
- 1x 001776 – O-ring (3rd stage)
- 1x 001722 – In- and outlet valve 1st stage
- 1x 001855 – In- and outlet valve 2nd stage
- 1x 001856 – In- and outlet valve 3rd stage
- 1x 001708 – Intake filter cartridge
- 1x 002309 – Breathing air filter cartridge
- 1x 000001 – Compressor oil (1l)

006709

Service Kit

LW 100 E ECO

LW 100 E

LW 100 E1 ECO

LW 100 E1

500 hours

- 1x 001810 – O-ring of water separator
 - 1x 001735 – Sintered filter of water separator
 - 1x 001769 – O-ring of final filter tower
 - 1x 001237 – O-ring of DIN filling connector
 - 1x 001224 – O-ring of rotatable hose
 - 1x 001708 – Intake filter cartridge
 - 1x 000644 – Breathing air filter cartridge
 - 1x 000001 – Compressor oil (1l)
-

003604

Service Kit LW 100 E/E1

1000 hours

- 1x 001810 – O-ring of water separator
- 1x 001735 – Sintered filter of water separator
- 1x 001769 – O-ring of final filter tower
- 1x 001237 – O-ring of DIN filling connector
- 1x 001224 – O-ring of rotatable hose
- 1x 001705 – Gasket (1st stage)
- 2x 001777 – O-ring (2nd and 3rd stage)
- 1x 001771 – O-ring (3rd stage)
- 1x 001781 – O-ring (1st stage)
- 1x 001768 – O-ring (2nd stage)
- 1x 001776 – O-ring (3rd stage)
- 1x 001722 – In- and outlet valve 1st stage
- 1x 001855 – In- and outlet valve 2nd stage
- 1x 001856 – In- and outlet valve 3rd stage
- 1x 001708 – Intake filter cartridge
- 1x 000644 – Breathing air filter cartridge
- 1x 000001 – Compressor oil (1l)